


OMEGA COMPRESSORS

For us, it's not just business. It's personal.

PUK-9030G




Spare Parts List

Ref. No.	Description	Part Number	Qty.
1	Horizontal Receiver	AR-H30G	1
2	Ball Valve	BV-25	1
3	Ball Valve	BV-50	1
4	Premium Gauge	GAL-25B2-300	1
5	Safety Valve	SV25-200	1
6	Check Valve	CV-N5050ST	1
7	Pilot Valve	PV25-LP	1
8	Pump	PUK-65	1
9	Gas Engine	GX270TQA6	1
10	Sheave/Pulley	2MAL44	1
11	Bushing	LX1	1
12	Throttle Control	TCSP-H-0811	1
13	A60 Belt	VBA60	2
14	Belt Guard	BG-2A	1

OMEGA COMPRESSORS

For us, it's not just business. It's personal.

MODEL : PUK-65



SPARE PARTS LIST

NO : QC-1903

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101055	3	21	Hexagon blot	2B00-SM08*020	4
2	Allen bolt set	3B01-M06*040V	12	22	Oil seal	2N50-TC24*47*07	1
3	In. & Ex. valve assembly	3B13-AC0765C	3	23	Pulley	3PBF-105A224	1
4	Double head screw set	3B11-001-A	12	24	Plate washer	2B30-08*35*35	1
5	Cylinder	3201035	3	25	Hexagon bolt set	3B00-SM08*035AV	1
6	Cylinder gasket	2G04-003	3	26	Rod set	3B33-H20371	1
7	Piston ring set	3B32-65N	3	27	Exhaust elbow	2N06-04T04HSS	1
8	Piston set	3B31-65N	3	28	Exhaust 3-way pipe	2N09-04H04T04H4	1
9	Rod set	3B33-H2048	2	29	Exhaust 3-way pipe	2N09-04H04T04H2	1
10	Crankcase	3301021	1	30	Exhaust tube set	3B2-04*195	2
11	Oil draining plug	2N33-002	2	31	Air filter set	2140020A	3
12	Oil sight gauge set	2303013A	1	32	Filter element	2142013	3
13	Oil filling plug set	2319003A	1	33	Unloading spring	2S03-001	3
14	Bearing	2N35-6205	1	34	O-ring	2N52-P06V	3
15	Crankshaft & balancer	3304046	1	35	Unloading piston	2113006	3
16	Pulley key	2N47-63*09	1	36	O-ring	2N52-P16*3V	3
17	Bearing	2N35-6205Z	1	37	Unloading nut	2B26-001	3
18	Rear bearing seat gasket	2G06-008	1	38	Unloading elbow	2N06-01T02H	1
19	Rear bearing seat	3311036	1	39	Unloading 3-way pipe	2N09-02H01T02H4	2
20	Breathing cover	2321008	1	40	Unloading tube set	3B2-02*395N	2